

AGES AND STAGES - GENERAL GUIDELINES

FRONT CARRY OUTWARD-FACING (<5 Months)
Min. 14 lbs / 6.4 kg
Max. -30 lbs / -13.6 kg

FRONT CARRY INWARD-FACING (<6 Months)
Min. 7 lbs / 3.2 kg
& Min. 20 inches / 50.8 cm
Max. 45 lbs / 20 kg

HIP CARRY (<6 Months)
Min. 17.2 lbs / 7.8 kg
Max. 45 lbs / 20 kg

BACK CARRY (<6 Months)
Min. 17.2 lbs / 7.8 kg
Max. 45 lbs / 20 kg

OMNI 360

OMNI 360 COOL AIR MESH

1 FOLLOW THESE EASY STEPS TO GET STARTED

1A Adjust the Omni 360 seat to your baby's height, using the velcro tabs

0 MONTH Min. 7 lbs / 3.2 kg
3 MONTHS
6 MONTHS
12 MONTHS Max. 45 lbs / 20 kg

HEIGHT
20 IN / 50.8 CM
24 IN / 61 CM
28 IN / 71 CM

1B Position the head and neck support according to baby's age and activity

0-6 weeks
7 weeks and up

1C Adjust the Omni 360 seat to face baby in or out, using the buttons or sliders

Min. 7 lbs / 3.2 kg
Min. 20 inches / 50.8 cm

(5 Months)
Min. 14 lbs / 6.4 kg
Max. -30 lbs / -13.6 kg

Min. 7 lbs / 3.2 kg
Min. 20 inches / 50.8 cm

(5 Months)
Min. 14 lbs / 6.4 kg
Max. -30 lbs / -13.6 kg

Omni 360

Omni 360 COOL AIR MESH

1D Squeeze & lift to unbuckle the shoulder straps if needed

Min. 14 lbs / 6.4 kg
Max. 45 lbs / 20 kg

Min. 17.2 lbs / 7.8 kg
Max. 45 lbs / 20 kg

Min. 14 lbs / 6.4 kg
Max. -30 lbs / -13.6 kg

Min. 17.2 lbs / 7.8 kg
Max. 45 lbs / 20 kg

2 BABY POSITIONING CHECKLIST & TIPS

2A Baby close enough to kiss, high on your body

2B Ergonomic "M" shape position with thighs supported

Adjust the seat to baby's height

2C Spine in "C" shape

2D Head supported at mid-ear level for babies 0-4 months and until baby has strong head and neck control.

0-4 Months

2E Open airway & visible face at all times

3 HOW TO ATTACH THE CARRIER WAISTBELT

4 FRONT CARRY INWARD-FACING WITH CRISSCROSS "X" STRAPS

Min. 7 lbs / 3.2 kg & Min. 20 inches / 50.8 cm

5 FRONT CARRY INWARD-FACING WITH PARALLEL "H" STRAPS

Min. 7 lbs / 3.2 kg & Min. 20 inches / 50.8 cm

6 FRONT CARRY OUTWARD-FACING WITH CRISSCROSS "X" STRAPS

Min. 14 lbs / 6.4 kg

7 FRONT CARRY OUTWARD-FACING WITH PARALLEL "H" STRAPS

Min. 14 lbs / 6.4 kg

8 HIP CARRY

Min. 17.2 lbs / 7.8 kg

OMNI 360

1 hood snap
2 hood
3 head & neck support buttons
4 pocket
5 waistbelt buckle
6 chest strap buckle
7 lumbar support
8 crisscross strap
9 head & neck support
10 head & neck support
11 shoulder strap buckle
12 safety elastic
13 buttons for seat adjustment
14 velcro tab for seat adjustment
15 detachable pouch

OMNI 360 COOL AIR MESH

1 hood snap
2 hood
3 head & neck support buttons
4 pocket
5 waistbelt buckle
6 chest strap buckle
7 lumbar support
8 crisscross strap
9 head & neck support
10 head & neck support
11 shoulder strap buckle
12 safety elastic
13 buttons for seat adjustment
14 velcro tab for seat adjustment
15 detachable pouch

ergobaby INSTRUCTION MANUAL

OMNI 360 ALL-IN-ONE BABY CARRIER

More tips and videos on ergobaby.com

THE ERGOBABY CARRIER, INC.
US: 617 285 7th St., Ste. 1000, Los Angeles, CA 90017
+1 215 285 2090 | info@ergobaby.com
EU: Mönckebergstraße 11, 20095 Hamburg, Germany
+49 40 421 065 0 | info@ergobaby.eu

Pat: www.ergobaby.com/patents
IM-BCOMI360ROW-190528-V2

